

www.BoeschPumps.com

# **Oil Sentinel**<sup>®</sup>

# OIL SENTINEL BT50 SERIES

60HZ-ANSI

2" FULL FREE PASSAGE SUBMERSIBLE SEWAGE PUMP

BOESCH PUMPS LLC

Art Chibli achibli@boeschpumps.com 14031 SW 143rd Court Miami, FL <u>33186</u>

# **///BOESCH**

# 60HZ BT SERIES

### **MOTOR / PUMP SPECIFICATIONS**

	ITEM	DESCRIPTION					
LIMITS	Liquid Temp	0~40°C					
LIMITS	Application	Commercial / Industrial / Municipal use					
	Frequency	60Hz					
	Motor	2P (3450RPM) Dry Motor					
	Insulation	Class B					
	Start Method	Direct On Line					
TYPE	Protection	IP 68					
	Protector	Auto-Cut					
	Bearing	Ball Type					
	Mech. Seal	Dual. Mechanical Seal					
	Impeller	Vortex Impeller					
	Motor Cover	AISI 316					
	Motor Housing+Stator	AISI 316					
	Shaft with Rotor	AISI 316					
MATERIAL	Mech. Seal	Upper: CA/CE; Lower: SIC/SIC					
	Pump Casing	AISI 316					
	Impeller	AISI 316					
	Cable	H07RN-F / SJTOW / STOW					



### **MOTOR / PUMP DATA CHART**


OUTPUT		DISCHARGE	PHASE		FREE PASSAGE	WEIGHT W/O CABLE		
HP	KW	INCHES	VOLTAGE	115V	208V	230V	INCHES	LBS
0.5	0.37	2	FULL	8A	4.4A	4A	1.4	29
1	0.75	2		12A	6.6A	6A	1.4	35
2	1.5	2(3)	-	-	12.2A	11A	1.8	69
3	2.2	2(3)		-	12.2A	11A	1.8	72
	HP	HP      KW        0.5      0.37        1      0.75        2      1.5	HP      KW      INCHES        0.5      0.37      2        1      0.75      2        2      1.5      2(3)	HP      KW      INCHES      VOLTAGE        0.5      0.37      2      7        1      0.75      2      FULL        2      1.5      2(3)      AMPS	HP      KW      INCHES      VOLTAGE      115V        0.5      0.37      2      8A        1      0.75      2      FULL      12A        2      1.5      2(3)      AMPS      -	HP      KW      INCHES      VOLTAGE      115V      208V        0.5      0.37      2      8A      4.4A        1      0.75      2      FULL LOAD AMPS      12A      6.6A        2      1.5      2(3)      AMPS      -      12.2A	HP      KW      INCHES      VOLTAGE      115V      208V      230V        0.5      0.37      2      8A      4.4A      4A        1      0.75      2      FULL LOAD AMPS      12A      6.6A      6A        2      1.5      2(3)      AMPS      -      12.2A      11A	OUTPUT      DISCHARGE      PHASE      10      PASSAGE        HP      KW      INCHES      VOLTAGE      115V      208V      230V      INCHES        0.5      0.37      2      8A      4.4A      4A      1.4        1      0.75      2      FULL LOAD AMPS      12A      6.6A      6A      1.4        2      1.5      2(3)      AMPS      -      12.2A      11A      1.8

MODEL	OUTPUT		DISCHARGE	PHASE	: 3Ø		FREE PASSAGE	WEIGHT W/O CABLE	
	HP	KW	INCHES	VOLTAGE	208V	230V	460V	INCHES	LBS
BT50/3	0.5	0.37	2		3.1A	2.8A	1.4A	1.4	28
BT100/3	1	0.75	2		4.4A	4A	2A	1.4	35
BT200/3	2	1.5	2(3)	FULL	7.7A	7A	3.5A	1.8	65
BT300/3	3	2.2	2(3)	LOAD	8.8A	8A	4.5A	1.8	69
BT500/3	4	3.7	3(4)	AMPS	16.6A	15A	8A	1.8	106
BT750/3	5	5.5	3(4)		23.2A	21A	10.5A	1.8	119

### **MOTOR / PUMP CONSTRUCTION MATERIAL**

PART	MATERIAL		PART	MATERIAL	
Cable	H07RN-F/STJOW/STOW		Mechanical Seal	Upper: CA / CE	
Handle	Nylon 6(0.5-1HP) AISI 316 (2-7.5HP)		Mechanical Seal	Lower: SIC / SIC	
Motor Cover	Motor Cover AISI 316		Seal Housing	AISI 316	
Bracket	Bracket ASTM A48 Class 30		Lip Seal	VITON	
Motor Housing + Stator	AISI 316		Impeller	AISI 316	
Shaft with Rotor AISI 316			Pump Casing	AISI 316	
Oil Chamber	ASTM A48 Class 30(0.5-1HP) AISI 316(2-7.5HP)		Upper/Lower Bearing	NTN/TPI	

# **MBOESCH** BT50








# 60HZ BT SERIES

## DIMENSIONAL DRAWING

MODELS: BT50 - BT100 (0.5~1HP)







MODEL	Α	A1	A2	В	B1	B2	D	D1	DN	н	H1	H2	H3	WT	
BT50	8.98	2.95	4.72	5.91	2.76	3.15	4.33	3.54	2	16.73	11.69	4.61	5.43	S:28.6	T:27.3
BT100	8.98	2.95	4.72	5.91	2.76	3.15	4.33	3.54	2	16.91	12.87	4.61	5.43	S:33.9	T:34.5

CWL: CONTINOUS RUNNING WATER LEVEL LWL: LOWEST RUNNING WATER LEVEL WT: WEIGHT WITHOUT CABLE S: SINGLE PAHSE T: THREE PHASE

DIMENSIONS: INCHES WEIGHT: LBS PIPE CONNECTION TYPE: NPT

## **BOESCH OIL SENTINEL**



The Boesch Oil Sentinel is used in elevator sump pits to remove water while retaining oil and other hydrocarbons. The Boesch Oil Sentinel is a UL listed system.







**Control Panel** 

Remote Alarm

Preset Level Sensor

## **KEY FEATURES**

#### ONE SENSOR

One preset level sensor for easy installation.

#### **REMOTE ALARM**

A remote alarm is included with the Oil Sentinel. Includes auxiliary contacts for High Oil, High Water and Pump Overload (on overload models).

#### MULTIPLE INDICATOR LIGHTS

Power On, Pump Run, High Water, High Oil and Pump Overload (on overload models).

#### ASME A17.1 COMPLIANT WORKS WITH AUTO DIALERS OR BAS

(Building Automation Systems)




**OPERATION OF DISCHARGE** 

Water and oil fill the elevator sump pit. As the sump is filling, the oil will float on top of the water. This layer of oil will not be pumped from the tank. The water underneath the oil will be pumped out through the discharge pipe to the sewer or other proper disposal area.


#### **1. WATER RISES & PUMP TURNS ON**

When the water reaches probe (#2) the system will turn on and pump the water out of the sump.




#### 2. WATER IS REMOVED/OIL CONTAINED

As the water is being pumped from the sump pit, the oil will remain floating on top of the water. **THE OIL WILL NOT BE PUMPED INTO THE SANITARY SEWER** 



3. PUMP TURNS OFF

When the water is pumped below probe (#1) the pump will turn off.



## PRESET LEVEL SENSOR AND CONTROL PANEL OPERATION



- ▶ When water touches probes (#1) and (#2) the pump will turn on.
- If the pump can not keep up, loses power or fails the water will reach probe (#3). The "High Water" light will illuminate on the control panel and the remote alarm will activate.
- If the water continues to rise the float switch will activate. If the float switch is activated and probe (#3) is touching water the "High Water" alarm will remain on. If OIL is touching probe (#3) and the float switch is activated, the "High Oil" light will illuminate and the remote alarm will activate.



14031 SW 143rd Court Miami, FL 33186 (305) 999 1769 & (786) 310 6988


sales@boeschpumps.com

# OIL SENTINEL CONTROL / ALARM SYSTEM



# **DESCRIPTION OF OPERATION**

On liquid rise, level reaches pump "Start" probe to start the pump. The pump will remain on until level is below "Off" probe. The "Off" probe senses air or oil and turns the pump off so the oil layer will not be pumped out of the tank. If the level reaches high level probe and high level float, the system will differentiate between water and oil and activate the remote alarm.



## **SPECIFICATIONS**


### Sensor

## **Control Panel**

- Housing: ABS
- Probe: Stainless Steel
  Float: PVC
- Enclosure: Type 1
- Power Cord: 6' SJT, 120 VAC
- Receptacle: 6" SJT, 120 VAC, 15 Amp

## **Alarm Panel**

- Enclosure: Type 1
  Power Cord: Plug in transformer, 120 VAC
   Backup Power: 9 VDC battery backup
- LED Alarm Indicators
- Audible Alarm: 103 db buzzer, auto/test rest
- Auxiliary Contact: High Water, High Oil, Optional Pump Fail



Revisio	on notes:		Drawn by:	Project:	Date:
Rev:	Date:	Notes:	C.Grajeda	BOESCH	06/14/2021
A	06/15/21	PROJECT			Scale@A3:
			Client:	Drawing Title:	XXXX
				OIL SENTINEL	Revision:
					A